

# **RD-1 RING DETECT POD**

ightarrow • • ightarrow QUICK START GUIDE


### WELCOME/INFORMATION

This Quick Start Guide provides information for installation and use of the RD-1 Ring Detect POD. The RD-1 POD is designed for use with phones that also support native "load detect" (LD) headset hookswitch control and works with Plantronics CS50, CS60, CS70, and Voyager 510S wireless headset families.


Once connected, the RD-1 POD will send a ringer alert signal to the headset anytime the phone rings, anywhere within a headset's wireless range. LD hookswitch control, for telephones that support it, enables on/off-hook functions directly from the headset using the headset's Call Control button so calls can be answered and ended remotely from the headset.

### INSTALLATION

Connect the audio cable from the headset base to the headset port on the telephone as shown in the diagram (required for LD hookswitch control); then connect the RD-1 POD as shown.



Connect the audio cable included with and pre-attached to the headset base to the headset port on telephone.



Connect the RD-1 POD cable to the headset base as shown; peel the adhesive off the back of the RD-1 microphone and attach to the telephone speaker.

See the user documentation included with the headset for further installation and product information.

**Note:** The RD-1 POD plus LD hookswitch control removes any requirement to attach the telephone handset to the headset base.

# IMPORTANT SAFETY INFORMATION

Please read the following instructions before use:

- The RD-1 POD is suitable for indoor use only.
- Use only with Plantronics CS50, CS60, CS70 and Plantronics Voyager 510S headsets.
- Do not spill liquid of any type on the product.
- Do not immerse in any type of liquid.
- To reduce the risk of electrical shock, do not disassemble this product yourself.
- Keep all products, cords, and cables away from operating machinery.

# USING RING DETECT AND CALL ANSWER/END FROM THE HEADSET

The headset will receive a ring alert signal from the headset base when the phone is ringing. To answer the call, press the Call Control button. To end the call, press the Call Control button again. The Call Control button can also be used to take the phone off-hook when placing a call.

### WARRANTY AND SERVICE

- Plantronics guarantees the satisfactory condition of the equipment with regard to manufacturing and material defects for 2 years from the date of purchase. (Please retain the original receipt and refer to the Limited Warranty Terms and Conditions, available at: www.plantronics.com/warranty, for warranty details and requirements).
- This product should be installed and used in accordance with the instructions detailed in this Quick Start Guide.
- . This does not affect your statutory rights.



## Plantronics, Inc.

345 Encinal Street Santa Cruz, CA 95060 USA

Tel: (800) 544-4660

#### www.plantronics.com

©2001 - 2007 Plantronics, Inc. All rights reserved. Plantronics, the logo design, RP-1, Plantronics Voyager, and Sound Innovation, are trademarks or registered trademarks of Plantronics, Inc. All other trademarks are property of their respective owners.

78282-01 (08/07)